


## User's Manual English

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.

### Description of the display and control buttons


#### Display elements 4210.B



#### Control buttons

- 01 Crown
- 01 Push-button

#### Display elements 4220.B



#### Control buttons


- 01 Crown
- 01 Push-button

### Setting the date/time

Example:

- Date / time on the watch: 17 / 1:25 AM
- Present date / time: 04 / 8:30 PM



- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown until yesterday's date appears 03.



- 3\* Pull out the crown to position III (the watch stops).
- 4 Turn the crown until the correct date 04 appears.
- 5\*\* Continue to turn the crown until the correct time 8:30 PM appears.


- 6 Push the crown back into position I.

**Please note:**  
\* To set your watch to the exact second, please refer to the chapter entitled «Setting the time».  
\*\* Please observe the AM/PM clock rhythm.



04

#### 4210.B Second 4220.B Small second



### Setting the time

- 1\* Pull out the crown to position III (the watch stops).
- 2 Turn the crown until you reach the correct time 8:45.
- 3\* Push the crown back into position I.

**Please note:**  
\* In order to set the time to the exact second, 3 must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, 3 must be pushed back into position I at the exact second.

02

### Setting the 2nd time zone

#### 4210.B



#### 4220.B



Any 2nd time zone can be set using the small hour hand and small minute hand.

- 1 **Activation:** Press the push button for at least 2 seconds. As soon as the small minute hand jumps forward one minute, this mode of operation is activated.
- 2 **Brief pressing:** (less than 1 second) Moves forward individual minutes.  
**Medium pressing:** (1 to 2 second) Moves forward 1 hour.  
**Long pressing** (longer than 2 seconds) The time zone is moved forward until the push button is released.

**Please note:**  
If the push button is not pushed for ten seconds, the setting mode is deactivated. Please see point no 1 for activation.



05

### Setting the date (quick mode)

- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown until the correct date 01 appears.
- 3 Push the crown back into position I.

**Please note:**  
During the date changing phase between approx. 9 PM and midnight, the date must be set to the date of the following day.

An extreme acceleration in setting the date with quick mode can induce a false date indication. The synchronization is re-established by setting the date from 01 till 31 (crown in position II).



03