

# RONDA xtratech – Movement cal. X20 / X30


## User's Manual English

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

**In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.**

### Description of the display and control buttons


#### Display elements X30



#### Control buttons

Crown

#### Display elements X20




#### Control buttons

Crown

01


### Setting the time



- 1\* Pull out the crown to position III (the watch stops).
- 2 Turn the crown until you reach the correct time.
- 3\* Push the crown back into position I.

#### Please note:

\* In order to set the time to the exact second, 1 must be pulled out when the second hand is in position «60». Once the hour and minute hands have been set, 3 must be pushed back into position I at the exact second.



02

Battery type: 395 / SR927SW  
Accuracy: +20 / -10 seconds per month



11/2022

### Setting the date (quick mode)

- 1 Pull out the crown to position II (the watch continues to run).
- 2 Turn the crown anticlockwise until the correct date appears.
- 3 Push the crown back into position I.

**Please note:**  
During the date changing phase between approx. 09:45 PM and midnight, the date must be set to the date of the following day.

03

### Setting the date, day of the week and time

- 1 Pull out the crown to position III (the watch stops).
- 2 Turn the crown anticlockwise until yesterday's day of the week appears.
- 3 Push the crown to position I.
- 4 Turn the crown until yesterday's date appears.
- 5\* Pull out the crown to position III (the watch stops).
- 6 Turn the crown anticlockwise until the correct date and day of the week appears.
- 7\*\* Continue to turn the crown anticlockwise until the correct time appears.
- 8 Push the crown back into position I.

**Please note:**  
\* To set your watch to the exact second, please refer to the chapter entitled «setting the time».  
\*\* Please observe the AM/PM clock rhythm.

04