User's Manual English Movements Caliber

– 715 – 715Li

RONDA - 585 - 505 - 515	powertech	RONDA slimtech - 1005 - 1006 - 1009 - 1015 - 1016 - 1019
RONDA	normtech	RONDA xtratech
RONDA - 774	_	RONDA xtratech – 6003.B
-		
- 774	- 6003.D	– 6003.B
– 774 – 775	- 6003.D	– 6003.B – 6004.B
- 774 - 775 - 704	- 6003.D	– 6003.B – 6004.B – 7002.B
- 774 - 775 - 704 - 705	- 6003.D	– 6003.B – 6004.B – 7002.B – 7003.B

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.
 Cal. 585
 Cal. 6003.D

 Cal. 505
 Cal. 6004.D

 Cal. 515
 Cal. 6003.B

 Cal. 6004.B
 Cal. 6004.B



Pos. I Position of rest (watch running)

Pos. II Quick-change correction for date

The date can also be corrected during the day-changing phase between 10 pm and midnight. The date of the following day has to be set, because no automatic date change takes place at midnight.

- Pull the crown out to position II (watch still running).
- Turn the crown clockwise until the required date appears.
- Cal. 6003.D & 6004.D:
- Turn the crown until the required date appears.
- Push the crown back into position I.

Pos. III Setting the time

- Pull the crown out to position III (watch stopped).
- Turn the crown, until the current time is displayed
- (remember the 24-hour cycle).
- Push the crown back into position I.

Cal. 774	Cal. 715Li
Cal. 775	
Cal. 704	Cal. 1005
Cal. 705	Cal. 1006
Cal. 784	Cal. 1009
Cal. 785	Cal. 1015
Cal. 714	Cal. 1016
Cal. 715	Cal. 1019



Pos. I Position of rest (watch running)

Pos. II Quick-change correction for date

- Blocking time for the quick-change day correction
- is from approx. 9.30 pm and midnight.
- Pull the crown out to position II (watch still running).
- Turn the crown until the current date appears.
- Push the crown back into position I.

Pos. III Setting the time

- Pull the crown out to position III (watch stopped).
- Turn the crown, until the current time is displayed (remember the 24-hour cycle).
- Push the crown back into position I.

Cal. 7002.B	
Cal. 7003.B	
Cal. 7004.B	



Pos. I Position of rest (watch running)

Pos. II Quick-change correction for date

The date can also be changed during the day-changing phase between approx. 8.00 pm and midnight. The date of the following day has to be set, because no automatic date change takes place at midnight.

- Pull the crown out to position II (watch still running).
- Turn the crown until the current date appears.
- Push the crown back into position I.

Pos. III Setting the time

- Pull the crown out to position III (watch stopped).
- Turn the crown, until the current time is displayed (remember the 24-hour cycle).
- Push the crown back into position I.

Cal. 585 / 785: Battery type: 362/SR721SW

Cal. 774 / 775 / 784: Battery type: 364/SR621SW

Cal. 505 / 515 / 704 / 705 / 714 / 715: Battery type: 371/SR920SW

Cal. 6003.D / 6004.D / 6003.B / 6004.B: Battery type: 373/SR916SW

Cal. 1005 / 1006 / 1009 / 1015 / 1016 / 1019: Battery type: 341/SR714SW

Cal. 7002.B / 7003.B / 7004.B: Battery type: 381/SR1120SW

Cal. 715Li: Battery type: CR 2016

Precision: +20/-10 seconds per month

