


2000.574.G 1.	Main plate
3305.275.CO 2.	Cannon pinion with driver (Aig.1)
2030.017.CO	Centre bridge
3.	Centre bridge held by 1 screw 4000.250.
4000.250 4. [™]	Screw
3001.055.FI 5. ⊯	Sliding pinion
3000.177.CO 6.	Setting stem
3017.049 7.	Setting lever
3905.049 8.	Setting lever jumper (3 positions) Setting lever jumper held by 1 screw 4000.250.
4000.250 9. T ⊚	Screw
3015.081 10.	Yoke (3 positions)
3905.067 11.	Yoke spring Tensioning the spring arm.
3406.030 12.	Pusher jumper B Put the grey jumper between the two posts on the further side.
3406.038 13. ∛	Pusher jumper A Put the yellow jumper between the two posts on the closer side.
3622.040 14.	Stator Mark Z on stator.
3622.039 15.	Stator (counter 6h, 9h and chrono)
	Stator (counter 6h, 9h and chrono)
3622.039 16.	





	3603.079 18.	Plastic bracket Plastic bracket held by 4 screws 4000.250.
	4000.250 19. Ⅲ ◎	Screw
	3715.094.RK 20.	Rotor
	3715.094.RK 21. ≜	Rotor
C	3147.046.CO 22. + •	Intermediate wheel
	3136.142.CO 23. † *	Second wheel (long)
	3147.047.CO 24. + •	Intermediate wheel (chrono)
	3136.143.CO 25. + •	Chronograph wheel (Aig.1)
	3122.056.CO 26.	Third wheel
	2020.148.G 27.	Train wheel bridge Train wheel bridge held by 3 screws 4000.250.
	4000.250 28. T ₪	Screw
	3715.095.RK 29. ậ ⊛	Rotor
	3147.048.CO 30. + ●	Intermediate wheel (counter)
	3402.006.CO 31.	Minute counting wheel
E		






2020.149.G 32.		Counter train wheel bridge Counter train wheel bridge held by 3 screws 4000.250.
4000.250 33. T	\bigcirc	Screw
3715.104.RK 34. ∮	۲	Rotor
3147.059.CO 35.	Ø	Intermediate wheel (counter 12h)
3402.006.CO 36.	$\overline{oldsymbol{\circ}}$	Minute counting wheel





2020.149.G 37.	Counter train wheel bridge Counter train wheel bridge held by 3 screws 4000.250.
4000.250 38. ฃ	Screw
3621.053.RK 39.	Coil Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.
3621.054.RK 40.	Coil (counter 9h, chrono) Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.
3621.054.RK 41.	Coil (counter 9h, chrono) Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.
3621.055.RK 42.	Coil (counter 6h) Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.
4000.250 43. Ⅲ ◎	Screw
3601.118 44.	Contact strip Contact strip held by 1 screw 4000.250.
4000.250 45. T ₪	Screw
3603.034 46.	Battery insulator
3612.210.5030 47.	Electronic module Electronic module held by 5 screws 4000.248. Electronic measurements may be realised now.
4000.248 48. T ₪	Screw
3603.069 49.	Circuit insulator
3601.107.G 50.	Pusher contact spring






2130.137.G.M01.5030D	Electronic module cover
51.	Electronic module cover held by 3 screws 4000.250.
3600.010.HGF 52.	Battery 395
3601.109.G	Bridle +
53.	Bridle held by 1 screw 4000.250.
4000.250 54. T ⊚	Screw

11/2019 N RONDA AG, Lausen, Switzerland, Phone ++41 (0)61 926 50 00, www.ronda.ch, info@ronda.ch



	2000.574.G 55.	Main plate
	3004.164 56.	Setting wheel
	3004.164 57.	Setting wheel
	3007.054.CO 58.	Minute wheel
J		
	2130.143 59.	Minute train bridge Minute train bridge held by 2 screws 4000.305.
	4000.305 60. ⊨ ⊚	Screw
	3301.241 61.	Hour wheel (Aig.1)
	3315.016 62.	Friction spring
	3004.224.CO 63.	Date indicator driving wheel
K	3500.049 64.	Date jumper
0 00	3504.208.AB.1.A 65.	Date indicator (standard) Nick of the indicator at 3 o`clock.
ST. D. D. R.	2130.141 66.	Date indicator maintaining plate Date indicator maintaining plate held by 1 screw 4000.250.
0 </td <td></td> <td></td>		





3905.070 67.	\bigcap	Date jumper spring Insert the date jumper spring in the provided opening.
2130.140.G 68.		Date mechanism maintaining plate Date mechanism maintaining plate held by 2 screws 4000.250.
4000.250 69. T		Screw
3506.072.G 70.	\bigcirc	Dial support
8200 71.	8	Moebius 8200
9014 72.	i	Moebius 9014
124 73.	8	Jismaa 124
9020 74.	I.	Moebius 9020