
## RONDA startech – Movement cal. 3520.D

## **User's Manual English**

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda Brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.





ise note


Continue to turn the crown until the correct time 8:30 PM appears.


Push the crown back into position I.

To set your watch to the exact second, please refer to the chapter entitled «setting the time». Please observe the AM/PM clock rhythm.










В



Chronograph: Basic function

Battery type: 384/SR41SW Accuracy: +20 / -10 seconds per month



11/2022